

## PIK CONNECTOR'S "CLICK"

This connector which is on the opposite end of the wire from the PIK Sensor has to make an audible "CLICK" when pushed together. If you do not hear the "CLICK" pull apart and do again.

